

DOMINATOR 1.X BASIC MANUAL



DOMINATOR 1.X - BOX



BUTTONS

Buttons

Restart button:

accessible by opening the box on the top of the protective casing. Warning! Pressing does Hardware restart of the Dominator and deletes all progress. Used between switching the scenarios or restarting a domination scenario. Meant only for GAMEMASTER

Colour buttons:

Colour buttons are accessible only from outside on the lid of the Dominator box. For exact functions and modes follow the "DECISION TREE" on the next slide. Meant both for GAMEMASTER as PLAYERS.



STARTING THE SYSTEM

PLACING THE BATTERY

In either case, place the battery always between the two foams!

Energy consumption: Dominator1.x consumes in average 650mAh per day.

To reduce the consumption use USB Powerbanks with low auto switch off current. (Power banks have internal control unit/circuit (ICU) that regulates performance. It manages flow of current through the device.)

You can test such a Powerbank by removing the red jumper. If Dominator stays on after 1 hour the consumption can be even 600mAh per day.

You can protect your Dominator 1.x from accessing by using the outer lock holes, ideal either for smaller padlocks or for zip-ties. Water resistance: 0,5mm on display pad side otherwise waterproof. Weather resistance: Keep away from direct sunlight, otherwise the buttons can burn your fingers. Operating temperature: from +10 till +40 Degree Celsius. Powerbank dependant Even when Dominator 1.x is able to operate in all weather conditions around the year. Protect it from direct Sunlight or direct rain or snow and use only batteries that are able to withstand such weather conditions.

**BEFORE STARTING THE DOMINATOR 1.X
PLEASE READ OPERATION MANUAL FIRST!**

**WE TAKE NO RESPONSIBILITY OR
LIABILITY, FOR ANY DAMAGES INCLUDING,
BUT NOT LIMITED TO:
INDIRECT OR CONSEQUENTIAL DAMAGES;
DAMAGES FOR LOSS OF OPPORTUNITY OR
CHANCE WHEN NOT FOLLOWING THE SET
OF RULES AND INSTRUCTIONS WRITTEN
ABOVE.**



BATTERY

Before first plugging the battery check if the battery is charged and in good condition.

Types of battery

Dominator 1.x does support one of two battery inputs. 1st /mainly from USB Powerbank with output 5V/2A max by correctly plugging in to the circuitboard via USB Mini port.

Please always double check connections! ! 2nd option is to power the Dominator 1.x via any DC Battery pack with correct polarity set and voltage not higher than 11V/2A max.. Be aware constant usage of this option may lead to premature wear/deterioration of such a battery pack. Please always double check the connections!

#THOUGHTBOX DESIGN DOMINATOR BOX SAFETY!



#THOUGHTBOX DESIGN